













Tamrac Lens Case Fit Chart

March 2009

|  |  MX5375 Lens Case Medium 3¼" Dia x 4½" H 8 x 11cm |  MX5378 Lens Case Large 3½" Dia x 6¾" H 9 x 17cm |  MX5341 Lens Case- Pro 50 4 Dia" x 6" H 10 x 15cm |  MX5343 Lens Case- Pro 100 3¾" Dia x 6¾" H 10 x 17cm |  MX5347 Lens Case- Pro 200 3¾ Dia" x 10" H 8 x 11cm |
|---|--|---|---|---|--|
| Canon | | | | | |
| EF 100-300mm f/4.5-5.6 USM | | √ | | | |
| EF 100-400mm f/4.5-5.6L IS USM | | | | | √ |
| EF 100mm f/2 USM | | √ | | | |
| EF 100mm f/2.8 Macro USM | | √ | | | |
| EF 135mm f/2.8 w/ Softfocus | | √ | | | |
| EF 135mm f/2L USM | | | | √ | |
| EF 14mm f/2.8L II USM | | | √ | | |
| EF 15mm f/2.8 Fisheye | √ | | | | |
| EF 16-35mm f/2.8L II USM | | | √ | | |
| EF 17-40mm f/4L USM | | | √ | | |
| EF 180mm f/3.5L Macro USM | | | | | √ |
| EF 200mm f/2.8L II USM | | | | √ | |
| EF 20mm f/2.8 USM | √ | | | | |
| EF 24-105mm f4L USM | | | | √ | |
| EF 24-70mm f/2.8L USM | | | | √ | |
| EF 24-85mm f/3.5-4.5 USM | √ | | | | |
| EF 24mm f/1.4L USM | | | √ | | |
| EF 24mm f/2.8 | √ | | | | |
| EF 28-105mm f/3.5-4.5 II USM | √ | | | | |
| EF 28-135mm f/3.5-5.6 IS USM | | √ | | | |
| EF 28-200mm f/3.5-5.6 USM | | √ | | | |
| EF 28-300mm f/3.5-5.6L IS USM | | | | | √ |
| EF 28-80mm f/3.5-5.6 II | √ | | | | |
| EF 28-90mm f/4-5.6 III | √ | | | | |
| EF 28mm f/1.8 USM | √ | | | | |
| EF 28mm f/2.8 | √ | | | | |
| EF 300mm f/4L IS USM | | | | | √ |
| EF 35mm f/1.4L USM | | | √ | | |
| EF 35mm f/2 | √ | | | | |
| EF 50mm f/1.2L USM | | | √ | | |
| EF 50mm f/1.4 USM | √ | | | | |
| EF 50mm f/1.8 II | √ | | | | |
| EF 50mm f/2.5 Compact Macro | √ | | | | |
| EF 70-200mm f/2.8L IS USM | | | | | √ |
| EF 70-200mm f/2.8L USM | | | | | √ |
| EF 70-200mm f/4L IS USM | | | | | √ |
| EF 70-200mm f/4L USM | | | | | √ |
| EF 70-300mm f/4.5-5.6 DO IS USM | | | | √ | |
| EF 70-300mm f4-f5.6 IS USM | | √ | | | |
| EF 75-300mm f/4-5.6 III | | √ | | | |
| EF 75-300mm f/4-5.6 III USM | | √ | | | |
| EF 85mm f/1.2L II USM | | | √ | | |
| EF 85mm f/1.8 USM | √ | | | | |
| EF-S 10-22mm f/3.5-4.5 USM | √ | | | | |
| EF-S 17-85mm f/4-5.6 IS USM | | √ | | | |
| EF-S 18-55mm f/3.5-5.6 USM | √ | | | | |
| EF-S 55-200mm f/4.5-5.6 II USM | | √ | | | |
| EF-S 60mm f/2.8 Macro USM | √ | | | | |
| Extenders EF 1.4x II | √ | | | | |
| Extenders EF 2x II | √ | | | | |
| Extension Tube EF 12 II | √ | | | | |
| Extension Tube EF 25 II | √ | | | | |







Tamrac Lens Case Fit Chart

March 2009

|  |  MX5375 Lens Case Medium 3¼" Dia x 4½" H 8 x 11cm |  MX5378 Lens Case Large 3½" Dia x 6¼" H 9 x 17cm |  MX5341 Lens Case- Pro 50 4 Dia" x 6" H 10 x 15cm |  MX5343 Lens Case- Pro 100 3¾" Dia x 6¾" H 10 x 17cm |  MX5347 Lens Case- Pro 200 3¾ Dia" x 10" H 8 x 11cm |
|---|--|---|---|---|--|
| Canon (Continued) | | | | | |
| Life Size Converter EF | √ | | | | |
| MP-E 65mm f/2.8 1-5x Macro | | | | √ | |
| TS-E 24mm f/3.5L | | | √ | | |
| TS-E 45mm f/2.8 | | | √ | | |
| TS-E 90mm f/2.8 | | | √ | | |
| Nikon | | | | | |
| AF 10.5mm f/2.8G ED AF DX Fisheye | √ | | | | |
| AF 105mm f/2D DC | | | | √ | |
| AF 135mm f/2D DC | | | | √ | |
| AF 14mm f.2.8D ED | | | √ | | |
| AF 16mm f/2.8D Fisheye | √ | | | | |
| AF 180mm f/2.8D IF ED | | | | | √ |
| AF 200mm f/4D IF ED Micro | | | | | √ |
| AF 20mm f/2.8D | √ | | | | |
| AF 24-85mm f/2.8-4D IF | | √ | | | |
| AF 24mm f/2.8D | √ | | | | |
| AF 28mm f/2.8D | √ | | | | |
| AF 300mm f/4D IF ED | | | | | √ |
| AF 35mm f/2D | √ | | | | |
| AF 50mm f/1.4D | √ | | | | |
| AF 50mm f/1.8D | √ | | | | |
| AF 70-300mm f/4-5.6G | | √ | | | |
| AF 80-200mm f/2.8D ED | | | | | √ |
| AF 80-400mm f/4.5-5.6D ED | | | | | √ |
| AF 85mm f/1.4D IF | | | √ | | |
| AF 85mm f/1.8D | √ | | | | |
| AF-S 105mm f/2.8G IF ED VR | | √ | | | |
| AF-S 14-24mm f/2.8G ED | | | √ | | |
| AF-S 16-85mm f/3.5-5.6G ED VR | | √ | | | |
| AF-S 17-35mm f/2.8D IF ED | | √ | | | |
| AF-S 17-55mm f/2.8G IF ED | | | | √ | |
| AF-S 18-135mm f/3.5-5.6G IF ED | | √ | | | |
| AF-S 18-200mm f/3.5-5.6G IF ED | | √ | | | |
| AF-S 18-55mm f/3.5-5.6G VR | √ | | | | |
| AF-S 18-70mm f/3.5-4.5G IF ED | | √ | | | |
| AF-S 24-120mm f/3.5-5.6G VR IF ED | | | | | √ |
| AF-S 24-70 f/2.8G ED | | | | √ | |
| AF-S 28-70mm f/2.8D IF ED | | | | √ | |
| AF-S 60mm f/2.8G Micro | | √ | | | |
| AF-S 70-200mm f/2.8G IF ED VR | | | | | √ |
| AF-S 70-300mm f/4.5-5.6G IF ED VR | | √ | | | |
| AF-S DX 12-24mm f/4G IF ED | | √ | | | |
| AF-S DX 55-200mm f/4-5.6G ED VR | | √ | | | |
| AF-S TC-14E II Teleconverter | √ | | | | |
| AF-S TC-17E II Teleconverter | √ | | | | |
| AF-S TC-20E II Teleconverter | √ | | | | |
| Olympus | | | | | |
| 7-14mm f/4.0 Zuiko | | | √ | | |
| 9-18mm f/4-5.6 ED Zuiko | √ | | | | |
| 11-22mm f/2.8-3.5 ED | | √ | | | |
| 12-60mm f/2.8-4 ED SWD Zuiko | | √ | | | |
| 14-35 f/2.0 ED SWD Zuiko | | √ | | | |







Tamrac Lens Case Fit Chart

March 2009

|  |  MX5375 Lens Case Medium 3¼" Dia x 4½" H 8 x 11cm |  MX5378 Lens Case Large 3½" Dia x 6¼" H 9 x 17cm |  MX5341 Lens Case- Pro 50 4 Dia" x 6" H 10 x 15cm |  MX5343 Lens Case- Pro 100 3¾" Dia x 6¾" H 10 x 17cm |  MX5347 Lens Case- Pro 200 3¾ Dia" x 10" H 8 x 11cm |
|---|---|--|--|--|---|
| Olympus (Continued) | | | | | |
| 14-42mm f/3.5-5.6 Zuiko ED | √ | | | | |
| 14-54mm f/2.8-3.5 II Zuiko | √ | | | | |
| 18-180mm f/3.5-6.3 ED Zuiko | √ | | | | |
| 35-100mm f/2.0 ED Zuiko | | | | | √ |
| 40-150mm f/4-5.6 Zuiko ED | √ | | | | |
| 50-200mm f/2.8-3.5 ED SWD Zuiko | | | | | √ |
| 70-300mm f/4-5.6 Zuiko ED | | √ | | | |
| 8mm f/3.5 Fisheye ED Zuiko | √ | | | | |
| 25mm f/2.8 ED Zuiko | √ | | | | |
| 35mm f/3.5 Macro ED | √ | | | | |
| 50mm f/2.0 Macro ED Zuiko | √ | | | | |
| 150mm f/2.0 ED | | | | √ | |
| Sigma | | | | | |
| 10-20mm f/4-5.6 EX DC HSM | | | √ | | |
| 12-24mm f/4-5.6 EX DG | | | | √ | |
| 15-30mm f/3.5-4.5 EX DG DF | | | | √ | |
| 17-35mm f/2.8-4 EX DG | √ | | | | |
| 17-70mm f/2.8-4.5 DC Macro | √ | | | | |
| 18-50mm f/2.8 EX | √ | | | | |
| 18-50mm f/3.5-5.6 DC | √ | | | | |
| 18-125mm f/3.8-5.6 DC | | √ | | | |
| 18-200mm f/3.5-6.3 DC OS | | √ | | | |
| 20-40mm f/2.8 | | | | √ | |
| 24-60mm f/2.8 EX DG | | | | √ | |
| 24-70mm f/2.8 EX DG | | | | √ | |
| 28-70mm f/2.8 EX DG | √ | | | | |
| 28-70mm f/2.8-4 DG | √ | | | | |
| 28-300mm f/3.5-6.3 DG | | √ | | | |
| 50-150mm f/2.8 EX DC APO HSM | | | | √ | |
| 50-500mm f/4-6.3 EX DG APO HSM | | | | | √ |
| 55-200mm 4-5.6 DC HSM | | √ | | | |
| 70-200mm f/2.8 DG APO HSM | | | | | √ |
| 70-300mm f/4-5.6 DG APO Macro | | √ | | | |
| 70-300mm f/4-56 DG | | √ | | | |
| 80-400mm f/4.5-5.6 EX DG APO OS | | | | | √ |
| 100-300mm f/4 EX DG APO IF HSM | | | | | √ |
| 120-400mm f/4.5-5.6 EX DG OS | | | | | √ |
| 135-400mm f/4.5-5.6 DG APO | | | | | √ |
| 170-500mm f/5-6.3 DG APO | | | | | √ |
| 4.5mm f/2.8 EX DC Circ Fisheye | √ | | | | |
| 8mm f/3.5 EX DG Circ Fisheye | √ | | | | |
| 10mm f/2.8 EX DC Fisheye | √ | | | | |
| 15mm f/2.8 EX DG Diagonal Fisheye | √ | | | | |
| 20mm f/1.8 EX DG DF RF | √ | | | | |
| 24mm f/1.8 EX DF DF Macro | √ | | | | |
| 28mm f/1.8 EX DG DF Macro | √ | | | | |
| 30mm f/1.4 EX DC HSM | √ | | | | |
| 50mm f/2.8 EX DG Macro | √ | | | | |
| 70mm f/2.8 EX DG Macro | √ | | | | |
| 105mm f/2.8 EX DG APO Macro | | √ | | | |
| 180mm f/3.5 EX DG APO Macro | | | | | √ |
| 1.4x EX DG DG APO Teleconverter | √ | | | | |

Tamrac Lens Case Fit Chart

March 2009

|  |  MX5375 Lens Case Medium 3¼" Dia x 4½" H 8 x 11cm |  MX5378 Lens Case Large 3½" Dia x 6¼" H 9 x 17cm |  MX5341 Lens Case- Pro 50 4 Dia" x 6" H 10 x 15cm |  MX5343 Lens Case- Pro 100 3¾" Dia x 6¾" H 10 x 17cm |  MX5347 Lens Case- Pro 200 3¾ Dia" x 10" H 8 x 11cm |
|---|---|--|--|--|---|
| Sony | | | | | |
| 2.0x EX DG DG APO Teleconverter | √ | | | | |
| 11-18mm f/4.5-5.6 DT | | √ | | | |
| 16-105mm f/3.5-506 | √ | | | | |
| 16-35mm f/2.8 ZA SSM Carl Zeiss | | √ | | | |
| 16-80mm f/3.5-4.5 Carl Zeiss Sonnar | | √ | | | |
| 16mm f/2.8 Fisheye | √ | | | | |
| 18-200mm f/3.5-6.3 DT | | √ | | | |
| 18-250mm f/3.5-6.3 | | √ | | | |
| 18-70mm f/3.5-5.6 | √ | | | | |
| 24-105mm f/3.5-4.5 | | √ | | | |
| 24-70mm f/2.8 Carl Zeiss Vario-Sonnar | | | | √ | |
| 55-200mm f/4-5.6 DT | | √ | | | |
| 70-200mm f/2.8 APO G SSM | | | | | √ |
| 70-300mm f/4.5-5.6 G SSM | | √ | | | |
| 70-400mm f/4-5.6 SSM | | | | | √ |
| 75-300mm f/4.5-5.6 | | √ | | | |
| 20mm f/2.8 AF | √ | | | | |
| 28mm f/2.8 | √ | | | | |
| 35mm f/1.4 G | √ | | | | |
| 50mm f/1.4 | √ | | | | |
| 50mm f/2.8 Macro | √ | | | | |
| 85mm f/1.4 Carl Zeiss Planar | √ | | | | |
| 100mm f/2.8 Macro | | √ | | | |
| 135mm f/1.8 Carl Zeiss Sonnar | | | √ | | |
| 135mm f/2.8 STF | | √ | | | |
| Tamron | | | | | |
| 17-35mm f/2.8-4 Di LD | | | √ | | |
| 28-75mm f/2.8 XR Di LD | √ | | | | |
| 28-300mm f/3.5-6.3 XR Di VC LD | | √ | | | |
| 28-200mm f/3.8-5.6 XR Di | | √ | | | |
| 70-300mm f/4-5.6 Di LD Macro | | √ | | | |
| 70-200mm f/2.8 Di LD IF Macro | | | | | √ |
| 200-500mm f/5-6.3 Di LD IF | | | | | √ |
| 90mm f/2.8 Di Macro | | √ | | | |
| 180mm f/3.5 Di LD IF Macro | | | | | √ |
| 11-18mm f/4.5-5.6 | | | √ | | |
| 17-50mm f/2.8 XR Di II | | √ | | | |
| 18-200mm f/3.5-6.3 XR Di II | | √ | | | |
| 18-250mm f/3.5-6.3 XR Di II | | √ | | | |
| 18-270mm f/3.5-6.3 Di II | | √ | | | |
| 55-200mm f/4-5.6 Di II | | √ | | | |
| 1.4x Teleconverter | √ | | | | |
| 2.0x Teleconverter | √ | | | | |
| Tokina | | | | | |
| 12-24mm f/4 AT-X Pro DX | | √ | | | |
| 11-16mm f/2.8 AT-X Pro DX | | √ | | | |
| 10-17mm f/3.5-4.5 AT-X DX | √ | | | | |
| 50-135mm f/2.8 AT-X Pro DX | | √ | | | |
| 16-50mm f/2.8 AT-X Pro DX | | √ | | | |
| 35mm f/2.8 AT-X Pro DX Macro | √ | | | | |
| 80-400mm f/4.5-5.6 | | | | | √ |
| 100mm f/2.8 Macro | | √ | | | |